

M series

Portable Cinema

Quick Start Guide

快速安装说明

快速入門指南

빠른 시작 가이드

クイックスタートガイド

Guide de démarrage rapide

Schnellstarthandbuch

Guía de inicio rápido

Guida introduttiva

Guia de Início Rápido

Průručka so stručným návodom

Vodnik za hitri začetek

Przewodnik Szybki start

короткий посібник користувача

Hızlı Başlangıç Kılavuzu

Snabbstartsguide

Vodič za brzo pokretanje

краткое руководство

по началу работы

Ghid de pornire rapidă

Első lépések

Οδηγός γρήγορης εκκίνησης

Pika-aloitusopas

Úvodní příručka

Vodič za brzi početak

Ръководство за бърз старт



Aan de slag

Panduan Mulai Cepat




Hướng dẫn Khởi động Nhanh

စွဲစီစဉ်စတင်စီစဉ်




دليل البدء السريع





5




6






2




3




4



7





9



iOS/ Android

(WiFi version only)

10



(WiFi version only)