


# Sliding Shower Enclosure Installation Instructions

## Right Hand

Image shows shower enclosure door moves leftwards.  
when door moves rightwards  
please mirror the installation  
process.



## Important Note on Safety Glass

In order to comply with European Regulatory Requirements, all of our shower enclosures/bath screens undergo a thermal toughening process.

This process makes the glass significantly stronger compared to standard glass, however in the unlikely event the glass should break during use, the glass in its entirety will shatter into small manageable fragments, the intention of this ensures avoiding large dangerously sharp shards of glass

# **Important - Please Read**

- Important: The wall plugs included in this pack are for solid walls only. If the product is to be mounted on a partition or stud wall, specialised fixings should be purchased separately-your local building merchant should be able to ensure you have the correct fixings for intended wall type.
- CAUTION!  
Before drilling into any walls check that there are no hidden cables or pipes. Exercise great care when using power tools near water. The use of a residual current device (RCD) or cordless drill is recommended. Always double check the positioning and measurements before drilling holes.
- This product is heavy and requires two people during lifting and installation.
- Glass is delicate, support on cardboard to minimise the risk of damage.

## **Product Information**

- Opening wall adjustments  
1000mm sliding - adjustment ⇒965-1005mm  
1200mm sliding - adjustment ⇒1165-1205mm


## **Installation Tips**

- Fixing tips; A piece of insulating tape or a couple of layers of masking tape applied to the wall before marking out the fixing holes will help stop the drill from wandering, particularly on tiled surfaces.
- When working near a basin or bath insert the plug into the waste, this will help you avoid losing small parts. Also take care not to drop accessories or tools onto the bath or basin, use a towel or bathmat to protect delicate surfaces.
- Do not fix the wall profile to newly plastered,painted or papered walls as chemical reaction may cause discolouration to surface finish.
- Check that the tray has been installed to the manufacturer's instructions.  
Please note-All product is supplied without a tray



















## **Legal statement**

- We have taken great care to ensure that this product reaches you in perfect condition. However should any parts be damaged or missing please contact your point of purchase. This does not affect your statutory rights. In addition if you require replacement parts your point of purchase will be happy to assist.














# IDENTIFICATION OF PARTS




## Fixings & fittings supplied

Item No.:	Part	Quantity	Item No.:	Part	Quantity
1	 Door Rails	x2	10	 ST3.5X10 Profile Screws	x6
2	 Fixed Glass	x1	11	 Screw cover caps	x12
3	 ST3.9X35 Wall Screws	x14	12	 Top Wheels	x2
4	 Door Stoppers	x2	13	 Bottom Wheels	x2
5	 ST3.9X9.5 Door Stopper Screws	x2	14	 Seal Strip For Fixed Glass	x1
6	 Profile(with magnetic strip)	x1	15	 Magnetic Strip	x1
7	 Aluminium Profiles	x2	16	 Glass Door	x1
8	 Seal Strip For Fixed Glass	x1	17	 Handle	x1
9	 Wall Plugs(Solid Walls)	x6	18	 Profile covers	x2

## Tools required(not supplied)

Electric Drill		pencil	
Ø3mm HSS drill bit		Silicone sealant gun	
Ø6 Masonry drill bit		Silicone sealant	
Cross-Head screwdriver		Spirit level	
Tape Measure		Rubber mallet	
Scissors		Eye Protection	
Gloves			



# ① ASSEMBLY INSTRUCTIONS




- Double check the dimensions of recess and ensure suitability of product.




$W1 > W2$




## ② ASSEMBLY INSTRUCTIONS




- Connect the fixed glass door (2) to guide rails (1) with screws (3).
- Fix the glass blocks (4) onto guide rails (1) with screws (5).
- Connect the profile (6) onto guide rails (1) with screws (3).




## ③ ASSEMBLY INSTRUCTIONS





- Insert one wall profile(7) onto fixed glass door.
- Install waterproof strip(8) onto glass.



## ④ ASSEMBLY INSTRUCTIONS




- Position another wall profile(7) using a spirit level to ensure Vertical alignment.
- Mark the positions of pre-drilled fixing holes on the wall profile(7)against the wall with a pencil.
- Drill the marked holes using a 6mm masonry drill bit.
- Using rubber hammer to install supplied wall plugs (9).
- Using screws(3) to fix wall profile (7)against the wall , then cover the cap (11).






# ⑤ ASSEMBLY INSTRUCTIONS




9

3

11



Ø6 Masonry drill bit












ST3.9X35

X3


X3

X3


- Insert the fixed door frame onto wall profile (7) .
- Position the door frame with spirit level.
- Use a pencil to mark the positions of the pre-drilled fixing holes.
- Drill the marked holes using a 6mm masonry drill bit.
- Use rubber hammer to install supplied wall plugs (9).
- Use screws(3) to fix wall profile (7)against the wall , then cover the cap (11).



## ⑥ ASSEMBLY INSTRUCTIONS




- Install the upper rollers (12) and bottom rollers (13) onto the glass door (16).
- Fix the glass door onto the top guide rail, then slide the seal strips (14) onto the glass door (16).
- Fix the magnetic strips (15) onto the glass door (16).











7

# ASSEMBLY INSTRUCTIONS






- There is 20mm of adjustment on each profile.
- Adjusting the upper rollers to make the magnetic stripe smooth.
- Drill holes into the wall channel using a 3mm HSS drill bit.CAREFUL-Do not drill all the way through the wall profiles(7)Only enough to insert the screws(10).
- Using screws(10) and caps (11) to fix the frame to the wall profiles(7).




⑧

# ASSEMBLY INSTRUCTIONS


-Using a scissor to cut reasonable size of the profile cover caps(18) to fix on the top of wall profiles.



## ⑨ ASSEMBLY INSTRUCTIONS



- Install the handle(17) on the sliding door.
- Apply silicone sealant to the outside of the sliding door.
- Please Note - Do not silicone inside the enclosure as this may cause issues with Drainage.



### CLEANING -general

Use only warm soapy water and damp cloth/sponge on a regular basis.  
Do not use abrasive scouring powders, chemicals or aerosol cleaners-these may result in damage to the surfaces, in particular, the plated component parts.

sealant drying times may vary in cold damp conditions and will be extended where thicker beads of sealant are applied.Allow sealant to dry completely before exposing to water.

We have taken great care to ensure that this product reaches you in perfect condition. However should any parts be damaged or missing please contact your point of purchase.This does not affect your statutory rights. In addition if you require replacement parts your point of purchase will be happy to assist.